

WHEELIE BIN SPILL KITS:

OIL SPILL KIT

The Oil Spill Response Kits are designed to contain incidental hydrocarbon spills, i.e. oils, fuels, etc.



CONTENTS

- 1 x 10 Kg XT 40 AbsorbSweep
- 1 x 5Lt OilGone XT
(extreme cleaner)
- 2 x 2m Absorbent Booms
- 1 x Absorbent Pillow
- 1 x Squeegee
- 1 x Broom
- 1 x Brush
- 1 x Spark proof shovel
- 2 x Pairs of Safety Gloves
- 2 x Safety Goggles and Masks
- 5 x Disposable Bags with
Cable Ties
- 1 x Mutton Cloth

NB. ALL PERSONNEL MUST BE FAMILIAR WITH THE LOCATION (ORANGE BIN CLEARLY MARKED SPILL RESPONSE KIT: OIL) AND APPLICATION OF SPILL RESPONSE KITS THIS IS TO ENSURE SAFE AND PROMPT SPILL CLEAN-UPS.

USER'S PROCEDURES

ALL SPILL RESPONSE KITS MUST ONLY BE USED FOR OIL AND FUEL SPILL CLEAN-UPS AND NOT FOR ANY OTHER CLEAN-UPS AS INCOMPLETE KITS WILL PREVENT THE USER TO PERFORM AN EFFECTIVE AND EFFICIENT CLEAN-UP.

1. Identify the source of the spill and rectify the situation as soon as possible.
2. Locate the spill kit and move to the spill site.
3. Break the bin seal to gain access to equipment.
4. Put on personal protective equipment, i.e. goggles, mask and gloves.
5. Use the absorbent booms (2x2m long flexible sausage shaped booms) to stop the spread of oil. Place the booms in the path of the oil as it spreads.
6. The pillow is used for the absorption of the oils and fuels on water. The XT 40 AbsorbSweep is used for the absorption of oil on soil or concrete.

SOIL OR CONCRETE

7. Spread XT 40 AbsorbSweep over spilt oil in a thick layer and ensure that the oil is completely covered.
8. Use the broom to sweep the XT 40 AbsorbSweep back and forth over the spill area to allow the XT40 AbsorbSweep to absorb the oil and to dry the area
9. Once all the oil has been absorbed, use the squeegee to move the powder together and scoop the powder into the disposal bags.
10. Scoop up the remaining residue using the spark proof shovel and place it in the disposal bags.
11. Pour OilGone XT Degreaser over the contaminated area and agitate it lightly with the broom.
12. Leave the degreaser for 5 to 10 minutes to emulsify the remaining oils.
13. Apply water and use the broom to wash the residue away to disposal.
14. Clean all equipment with degreaser.
15. Seal the disposal bags with cable ties and dispose of according to regulations.

WATER

16. Put the pillow on the oil floating on the water and move it back and forth with the broom to allow the pillow to absorb the oil.
17. The pillow and booms will not sink even if it is completely saturated with oil.
18. Once the oil is absorbed, remove the pillow and booms from the water and place into the disposal bags.
19. Seal the disposal bags with cable ties and dispose of according to regulations.

FINALLY

20. Return all equipment to the wheelie bin and contact the person responsible to replace the used contents and re-seal the bin.



HEAD OFFICE CONTACT DETAILS:

Unit 4 Princess Square, 1 President Road, Roodepoort 1724
P. O. Box 4553, Cresta 2118
Telephone: **0861114821** / +27 (0) 11 477 4100
Emergency: (0)83 376 1650 • Fax: 0866428349
e-mail: info@ensa.co.za • www.ensa.co.za



Cleans the environment like nothing on earth

WHEELIE SPILL KITS